

SIGNS

Yard Arm Installation



Two rooks are used for each galvanized pipe. Be sure to install both rooks on the post before driving the post into the ground.



They slide over the pipe and are fastened with stainless steel screws after the post is driven into the ground.



Mark a heavy line on the pole to indicate where ground level will be and how far the pipe needs to be driven into the ground.



Drive the pole into the ground so your marked line is level with the ground.



Adjust your rooks and fasten them to the post with the screws provided.



Once the pole is upright, just slide the post sleeve down over the pipe.



Connect Cross Arm and Support Rail.



Install eyebolts and hang your sign!